

Parts No.	Description	Model No.	Description	Item No.	Q'ty
643653-8	Brush holder 6.5X13.5	1805B	POWER PLANER 155MM	010	2
643653-8	Brush holder 6.5X13.5	1805B	POWER PLANER 155MM	010-1	2
643653-8	Brush holder 6.5X13.5	1806B	POWER PLANER 170MM	009	2
643653-8	Brush holder 6.5X13.5	1806B	POWER PLANER 170MM	009-1	2
643653-8	Brush holder 6.5X13.5	2012	PLANER 304MM	020	2
643653-8	Brush holder 6.5X13.5	2012	PLANER 304MM	020-1	2
643653-8	Brush holder 6.5X13.5	2012NB	PLANER 304MM	041	2
643653-8	Brush holder 6.5X13.5	2412N	CUT-OFF 305MM	032	2
643653-8	Brush holder 6.5X13.5	2412N	CUT-OFF 305MM	032-1	2
643653-8	Brush holder 6.5X13.5	2414	CUT-OFF 355MM	032	2
643653-8	Brush holder 6.5X13.5	2414	CUT-OFF 355MM	032-1	2
643653-8	Brush holder 6.5X13.5	2414K	PORTABLE CUT-OFF 355MM	032A_	2
643653-8	Brush holder 6.5X13.5	2702	TABLE SAW 210MM	073	2
643653-8	Brush holder 6.5X13.5	2704	TABLE SAW 255MM	033	2
643653-8	Brush holder 6.5X13.5	2704N	260MM TABLE SAW	033	2
643653-8	Brush holder 6.5X13.5	3600B	ROUTER 12MM	038-2	2
643653-8	Brush holder 6.5X13.5	3612BR	ROUTER 12MM	003	2
643653-8	Brush holder 6.5X13.5	4107R	CUTTER 180MM	056	2
643653-8	Brush holder 6.5X13.5	4107R	CUTTER 180MM	056-1	2
643653-8	Brush holder 6.5X13.5	5008-MG	CIRCULAR SAW 210MM	045	2
643653-8	Brush holder 6.5X13.5	5008-MG	CIRCULAR SAW 210MM	045-1	2
643653-8	Brush holder 6.5X13.5	5012B	CHAIN SAW 300MM	041C1	2
643653-8	Brush holder 6.5X13.5	5014B	CHAIN SAW 335MM	038C1	2
643653-8	Brush holder 6.5X13.5	5014NB	CHAIN SAW 340MM	082B_	2
643653-8	Brush holder 6.5X13.5	5016NB	CHAIN SAW 375MM	082	2
643653-8	Brush holder 6.5X13.5	5100BR	CIRCULAR SAW 335MM	006	2

643653-8	Brush holder 6.5X13.5	5100BR	CIRCULAR SAW 335MM	006-1	2
643653-8	Brush holder 6.5X13.5	5500S	TENONING MACHINE	096	2
643653-8	Brush holder 6.5X13.5	5500S	TENONING MACHINE	292	2
643653-8	Brush holder 6.5X13.5	5900BR	CIRCULAR SAW 235MM	001A1	2
643653-8	Brush holder 6.5X13.5	7104L	CHAIN MORTISER	015B1	2
643653-8	Brush holder 6.5X13.5	7104L	CHAIN MORTISER	015B_	2
643653-8	Brush holder 6.5X13.5	9105	STRAIGHT GRINDER 125MM	034-2	2
643653-8	Brush holder 6.5X13.5	9105	STRAIGHT GRINDER 125MM	034-3	2
643653-8	Brush holder 6.5X13.5	9402	2-SPEED BELT SANDER 100MM	002	2
643653-8	Brush holder 6.5X13.5	ES-163A	CHAIN SAW 350MM	027	2
643653-8	Brush holder 6.5X13.5	ES-173A	CHAIN SAW 400MM	027	2
643653-8	Brush holder 6.5X13.5	ES-2130A	CHAIN SAW 300MM	027	2
643653-8	Brush holder 6.5X13.5	ES-2135A	CHAIN SAW 350MM	027	2
643653-8	Brush holder 6.5X13.5	ES-2140A	CHAIN SAW 400MM	027	2
643653-8	Brush holder 6.5X13.5	ES-2145A	CHAIN SAW 450MM	027	2
643653-8	Brush holder 6.5X13.5	ES2131TLC	ELECTRIC CHAIN SAW 300MM	012	2
643653-8	Brush holder 6.5X13.5	ES2136TLC	ELECTRIC CHAIN SAW 350MM	012	2
643653-8	Brush holder 6.5X13.5	ES2141TLC	ELECTRIC CHAIN SAW 400MM	012	2
643653-8	Brush holder 6.5X13.5	HM1200	DEMOLITION HAMMER	053-1	2
643653-8	Brush holder 6.5X13.5	HM1200	DEMOLITION HAMMER	053-2	2
643653-8	Brush holder 6.5X13.5	HM1200B	DEMOLITION HAMMER	053	2
643653-8	Brush holder 6.5X13.5	HM1200B	DEMOLITION HAMMER	053-1	2
643653-8	Brush holder 6.5X13.5	HM1200K	DEMOLITION HAMMER	064-1	2
643653-8	Brush holder 6.5X13.5	HM1200K	DEMOLITION HAMMER	064-2	2
643653-8	Brush holder 6.5X13.5	HM1202C	DEMOLITION HAMMER	076	1
643653-8	Brush holder 6.5X13.5	HM1202C	DEMOLITION HAMMER	076-1	1
643653-8	Brush holder 6.5X13.5	HM1242C	DEMOLITION HAMMER	076	1

643653-8	Brush holder 6.5X13.5	HM1242C	DEMOLITION HAMMER	076-1	1
643653-8	Brush holder 6.5X13.5	HR3850	ROTARY HAMMER 38MM	079-1	2
643653-8	Brush holder 6.5X13.5	HR3850	ROTARY HAMMER 38MM	079-2	2
643653-8	Brush holder 6.5X13.5	HR3850B	ROTARY HAMMER 38MM	076-2	2
643653-8	Brush holder 6.5X13.5	HR3850B	ROTARY HAMMER 38MM	076-3	2
643653-8	Brush holder 6.5X13.5	HR3850K	ROTARY HAMMER 38MM	079-1	2
643653-8	Brush holder 6.5X13.5	HR3850K	ROTARY HAMMER 38MM	079-2	2
643653-8	Brush holder 6.5X13.5	HR4500C	ROTARY HAMMER 45MM	132	1
643653-8	Brush holder 6.5X13.5	HR5000	ROTARY HAMMER 50MM	078-2	2
643653-8	Brush holder 6.5X13.5	HR5000K	ROTARY HAMMER 50MM	078-2	2
643653-8	Brush holder 6.5X13.5	HR5001C	ROTARY HAMMER 50MM	134	1
643653-8	Brush holder 6.5X13.5	HS0600	260MM CIRCULAR SAW	050	2
643653-8	Brush holder 6.5X13.5	HS6100	165MM CIRCULAR SAW	008	2
643653-8	Brush holder 6.5X13.5	HS6101	165MM CIRCULAR SAW	008	2
643653-8	Brush holder 6.5X13.5	HS7100	190MM CIRCULAR SAW	008	2
643653-8	Brush holder 6.5X13.5	HS7101	190MM CIRCULAR SAW	008	2
643653-8	Brush holder 6.5X13.5	LF1000	FLIP OVER SAW 260MM	026	2
643653-8	Brush holder 6.5X13.5	LH1040	TABLE TOP MITER SAW 260MM	062-1	2
643653-8	Brush holder 6.5X13.5	LH1040F	TABLE TOP MITER SAW 260MM	062-1	2
643653-8	Brush holder 6.5X13.5	LS1030	MITER SAW 255MM	018B_	2
643653-8	Brush holder 6.5X13.5	LS1040	MITER SAW 255MM	021D2	2
643653-8	Brush holder 6.5X13.5	LS1040F	MITER SAW 255MM	021-2	2
643653-8	Brush holder 6.5X13.5	LS1440	MITER SAW 355MM	013D_	2
643653-8	Brush holder 6.5X13.5	M9400	BELT SANDER	023-1	2
643653-8	Brush holder 6.5X13.5	MT941	BELT SANDER	023	2
643653-8	Brush holder 6.5X13.5	N5900B	CIRCULAR SAW 235MM	048-1	2
643653-8	Brush holder 6.5X13.5	SR2600	CIRCULAR SAW 266MM	033	2

643653-8	Brush holder 6.5X13.5	TW1000	IMPACT WRENCH	030	2
643653-8	Brush holder 6.5X13.5	UC3030A	CHAIN SAW 300MM	027	2
643653-8	Brush holder 6.5X13.5	UC3051A	ELECTRIC CHAIN SAW 300MM	012	2
643653-8	Brush holder 6.5X13.5	UC3530A	CHAIN SAW 350MM	027	2
643653-8	Brush holder 6.5X13.5	UC3550A	ELECTRIC CHAIN SAW 350MM	012	2
643653-8	Brush holder 6.5X13.5	UC3551A	ELECTRIC CHAIN SAW 350MM	012	2
643653-8	Brush holder 6.5X13.5	UC4030A	CHAIN SAW 400MM	027	2
643653-8	Brush holder 6.5X13.5	UC4050A	ELECTRIC CHAIN SAW 400MM	012	2
643653-8	Brush holder 6.5X13.5	UC4051A	ELECTRIC CHAIN SAW 400MM	012	2
643653-8	Brush holder 6.5X13.5	UC4530A	CHAIN SAW 450MM	027	2
643653-8	Brush holder 6.5X13.5	UC4551A	ELECTRIC CHAIN SAW 450MM	012	2